


B2BCatalogGeoSingleVision

b2bOpticLensCatalog→lensGeos→lensGeo



bgcToPrp	
type	B2BCatalogInUp
unity	mm
occurs	1
description	distance between the geometrical center of the lens (BGC) and the prism reference point (PRP)
prpToLrp	
type	B2BCatalogInUpRange
unity	mm
occurs	0..1
description	distance between the prism reference point (PRP) and the layout reference Point (LRP)
prpToDrp	
type	B2BCatalogInUpRange
unity	mm
occurs	0..1
description	distance between the prism reference point (PRP) and the distance reference Point (DRP)
prpToMe	
type	B2BCatalogInUp
unity	mm
occurs	0..1
description	distance between the prism reference point (PRP) and the microengravings (Me) the distance from the PRP to the right and left microengraving is equal

```
<xs:complexType name="B2BCatalogGeoSingleVision">
  <xs:sequence>
    <xs:element name="bgcToPrp" type="B2BCatalogInUp"/>
    <xs:element minOccurs="0" name="prpToLrp" type="B2BCatalogInUpRange"/>
    <xs:element minOccurs="0" name="prpToDrp" type="B2BCatalogInUpRange"/>
    <xs:element minOccurs="0" name="prpToMe" type="B2BCatalogInUp"/>
  </xs:sequence>
</xs:complexType>
```

</xs:complexType>

From:
<https://wiki2.b2boptic.com/> - **wiki2.b2bOptic.com**

Permanent link:
<https://wiki2.b2boptic.com/en:lenscatalog:version070000:complextypes:b2bcataloggeosinglevision>

Last update: **2017/07/10 13:59**

